






e-Guide to RF Signals

UNLICENSED & ISM BANDS | LAND MOBILE & PUBLIC SAFETY | CELLULAR | AERONAUTICAL | RADIO & TELEVISION BROADCAST | WEATHER RADAR






A Guide to The Radio Spectrum




<p>Unlicensed and ISM Bands</p>	<p>Unlicensed bands – constrained by power and frequency, many consumer (Wi-Fi, Key FOBS) and medical devices use these frequencies.</p>	<p>Example Application</p> <ul style="list-style-type: none"> WLAN 802.11b WLAN 802.11g Microwave Oven DECT cordless phone Bluetooth
<p>Land Mobile and Public Safety</p>	<p>Trunked radio, Public and Private Mobile Radio, Distributed</p>	<p>Example Application</p> <ul style="list-style-type: none"> P25 Narrow band FM NXDN
<p>Cellular</p>	<p>Extremely crowded and expensive spectrum. Used for mobile data and voice communications. Often replaces a hard wired communication line.</p>	<p>Example Application</p> <ul style="list-style-type: none"> LTE Downlink LTE Uplink UMTS Downlink UMTS Uplink GSM
<p>Aeronautical</p>	<p>Civilian flight control and communications bands. Includes Radars for aircraft tracking and navigation, communications, IFF</p>	<p>Example Application</p> <ul style="list-style-type: none"> VOR Tower Communications ATIS
<p>Radio and Television Broadcast</p>	<p>Broadcast frequencies – Radio and Television applications, including short wave and hobbyist spectrum. sometimes under-utilized, long time owned by broadcasters</p>	<p>Example Application</p> <ul style="list-style-type: none"> FM Radio ATSC TV
<p>Weather Radar</p>	<p>Commonly used spectrum for radar, electronic warfare, and communications. Could be land, sea, air or space based systems</p>	<p>Example Application</p> <ul style="list-style-type: none"> Weather Radar

What's A Spectrum Display? | What's A Spectrogram Display? | What Is A Real-Time Display? | Signal Classification 101



What's A Spectrum Display?

Additional Information:




A spectrum analyzer is the tool of choice for people who need to “see” a radio signal. In general most spectrum analyzers provide the same display; they show lower frequency signals on the left hand side of the display and higher frequency signals on the right hand side of the display. The three basic controls for most spectrum analyzers are; Frequency, Span & Amplitude (Reference Level). With these three controls we can control the view of the spectrum. The next question is “what am I looking at” ?

We can tell a lot about an RF signal from the basic spectrum display. It certainly helps to know what you are looking for.. Around the world there is a lot of dedicated spectrum assignment, meaning certain frequency ranges are used for certain types of radio signals.

The first step in identifying a radio signal is to determine the operating frequency of the transmitter. Other than Industrial/Scientific/Medical bands, the radio spectrum is a tightly managed resource. When we are trying to determine what type of signal we are seeing, we need to first identify the operating frequency. A simple technique is to look at the total width of the signal and find the mid-point in the signal. In general this will indicate the operating frequency. With this first piece of information we can now research frequency assignment tables to determine what type of radio service may be assigned to specific frequency.


The second piece of information that is important is how “wide” the signal is that is shown on the spectrum display. The “width” or occupied bandwidth of the signal provides us additional information regarding the class of service of the transmitter. We know for example that in the 2.4 GHz ISM frequency band, a Bluetooth signal is approximately 1 MHz wide but a Wifi signal could be up to 40 MHz wide.

In summary, the basic spectrum display allows us to determine the frequency, occupied bandwidth and relative strength of a radio transmitter.



What's A Spectrogram Display?

Additional Information:




While it's very important to determine frequency, occupied bandwidth and relative signal strength; we also need to find out how often a signal is on.

The spectrogram display is the one of the best ways for us to measure this aspect of a signal. Like the spectrum display the spectrogram shows low frequencies on left and higher frequencies on the right. What makes this display different is that color represents the amplitude of the signal, and the Y-Axis. You can think of a spectrogram as a strip chard recorder measuring power and frequency over a time period.


The spectrogram provides important information as it can tell us how often a signal is present, and indicates if the operating frequency is changing over time. These two pieces of information are critical in identifying the class of service of a particular emission.

Armed with frequency, occupied bandwidth, and time data; it is possible to make accurate assessments of the type of radio emitter that is being analyzed.



What Is A Real-Time Display?

Additional Information:




In the past decade there has been a gradual shift toward real-time spectrum displays. While classic spectrum displays have been around since the 1960's, they have all suffered from a common problem, speed. In most traditional spectrum analyzers what is displayed on the left hand side of the display and the right hand side of the display is not measured at the same time. The instrument sweeps across the frequency range making measurements over time. To overcome this shortcoming spectrum analyzers employ specific trace modes (max hold, min hold, average etc) to improve the ability of the analyzer to measure a specific signal.

Real time spectrum analyzer are function and operate the same way traditional spectrum analyzers. The difference with real time analyzer is that in up to the maximum real time span, these analyzer do not sweep the spectrum, but rather instantaneously digitize the whole span. The span is limited by the instantaneous bandwidth of the instrument they can digitize signals extremely quickly. Real time spectrum analyzers with that capability can produce results


measured in thousands of traces per second. This has led to an upgrade of the basic spectrum display with the Digital Phosphor Display (DPX). In the DPX display we still have low frequency on the left and high frequency on the right hand side of the display.

Rather than producing a single trace real time analyzer are able to keep tracks of how often a signal is measured for each pixel in the display. There is a counter behind each pixel that keeps track of how often energy is measured, and the pixel color is based on this counter. Real time analyzer also employ a decay function, just like what was found on old fashioned CRT displays. This combination provides an extremely useful tool for analyzing fast frequency hopping signals like Bluetooth, or for isolating tough transients that can be virtually invisible to slow sweeping spectrum analyzers.



Signal Classification 101

Additional Information:



Identifying signals you measure with a spectrum analyzer can be difficult even with the best of tools. The radio spectrum is a shared resource and the propagation characteristics change for each frequency band.

What follows are some guiding principals about radio transmissions. When you find a signal of interest, whether this is signal that should or should not be present in a particular frequency band, you would want to start with the basics.

The first step is to look at the frequency, bandwidth, and shape of a signal of interest to get an idea about the characteristics & therefore the identity of this signal.


For example, many of the 3G and 4G signals have square tops due to the type of filtering they use. Also, these commercial wireless signals use predicable bandwidths. You can make an educated guess on the signal type based on what you see on the screen.

Other signal types will have different information bandwidths and different filtering employed, therefore they will have a different shape on the Spectrum Analyzer display or the Real-Time display of an analyzer.

The second step is to perform modulation analysis of the signal. Analyzing the modulation will give further insight into more of the unique characteristics of a signal. The fastest, simplest, and most common way of doing this is to take advantage of a spectrum analyzer's Audio Demodulation feature – to play the FM or AM audio out the instrument of the signal of interest. Your ear can hear differences in signals.

There are limitations using this method, for example the Audio Demodulation of an analyzer may have a much smaller bandwidth compared to the signal of interest bandwidth. However, there are often distinguishable sounds from various signals seen throughout the spectrum, and this method is a proven technique to help identify signals.

The third step is to capture the signal data and perform additional analysis of the signal. This can be a difficult technique because based on some experience, trial and error would be used within the RF measurement software capabilities to try to determine more characteristics of the signal. For example, you could look at the RF IQ vs. Time to try to figure out a digital modulation Symbol Rate, or look at the Spectrogram to try to check for the presence of OFDM subcarriers.



- LF
- HF
- VHF
- UHF
- SHF

Unlicensed and ISM Band: WiFi – 802.11b

Technical Overview



- Modulation: CCK
- Source: Data
- Channel Bandwidth: 20 MHz
- Channel Occupancy: Burst

Example Application


- Wireless Ethernet

Common Frequency Range

- 2.412 GHz – 2.483 GHz



Additional Information:



- LF
- HF
- VHF
- UHF
- SHF

Unlicensed and ISM Band: WiFi – 802.11g

Technical Overview



- Modulation: OFDM
- Source: Data
- Channel Bandwidth: 20 MHz
- Channel Occupancy: Burst

Example Application



- Wireless Ethernet

Common Frequency Range

- 2.412 GHz – 2.483 GHz



Additional Information:



Unlicensed and ISM Band: Microwave Oven

Technical Overview



- Modulation: CW
- Source: None
- Channel Bandwidth: 20 MHz
- Channel Occupancy: Continuous

Example Application


- Warming Food

Common Frequency Range

- 2.412 GHz – 2.483 GHz



Additional Information:



LF
HF
VHF
UHF
SHF

Unlicensed and ISM Band: DECT

Technical Overview



- Modulation: GFSK
- Source: Data
- Channel Bandwidth: < 2.5 MHz
- Channel Occupancy: Time Division Access

Example Application


- Cordless phone
- Hands free device

Common Frequency Range

- 1880 MHz – 1930 MHz
- 2.412 GHz – 2.483 GHz



Additional Information:



LF
HF
VHF
UHF
SHF

Unlicensed and ISM Band: Bluetooth

Technical Overview



- Modulation: GFSK, pi/4 DQPSK, 8DPSK
- Source: Data
- Channel Bandwidth: ~ 1 MHz
- Channel Occupancy: TDMA

Example Application


- Wireless Audio
- Wireless Networking
- Ad-Hoc Networking

Common Frequency Range

- 2.402 GHz – 2.483 GHz



Additional Information:



Land Mobile Radio: P25 Phase 1

Technical Overview



- Modulation: FM
- Source: Voice/Data
- Channel Bandwidth: 6k-25kHz
- Channel Occupancy: Bursted & Steady State

Example Application


- Government Services
- Public Safety
- Marine Communications
- Paging
- Amateur Radio

Common Frequency Range

- 25 MHz – 49.6 MHz
- 138 MHz – 174 MHz
- 410 MHz – 512 MHz
- 806 MHz – 902 MHz
- 928 MHz – 975 MHz



Additional Information:



Land Mobile Radio: Narrow Band FM

Technical Overview



- Modulation: FM
- Source: Voice/Data
- Channel Bandwidth: 6k-25kHz
- Channel Occupancy: PTT & Steady State

Example Application



- Government Services
- Public Safety
- Marine Communications
- Paging
- Amateur Radio

Common Frequency Range

- 25 MHz – 49.6 MHz
- 138 MHz – 174 MHz
- 410 MHz – 512 MHz
- 806 MHz – 902 MHz
- 928 MHz – 975 MHz



Additional Information:



Land Mobile Radio: NXDN

Technical Overview



- Modulation: FSK
- Source: Data
- Channel Bandwidth: < 25 kHz
- Channel Occupancy: PTT

Example Application



- Cellular Networks
- Public Safety
- Portable Internet

Common Frequency Range

- 138 MHz – 174 MHz
- 410 MHz – 512 MHz
- 806 MHz – 902 MHz
- 928 MHz – 975 MHz



Additional Information:



Radio and Television Broadcast: FM

Technical Overview



- Modulation: FM
- Source: Mono/Stereo Audio
- Channel Bandwidth: 250kHz-300kHz
- Channel Occupancy: Steady State
- Multiplexed modulation with sub-carriers

Example Application



- Broadcast
- Government
- Transmitter links with SCMO
- Wide Area Paging

Common Frequency Range

- 88MHz – 108 MHz



Additional Information:



Radio and Television Broadcast: ATSC – Terrestrial TV

Technical Overview



- Modulation: 8VSB
- Source: Data
- Channel Bandwidth: 6 MHz
- Channel Occupancy: Steady State

Common Frequency Range


- 54 MHz – 88 MHz
- 174 MHz – 216 MHz
- 470 MHz – 806 MHz
- ATSC Frequencies NA

Example Application

- Broadcast Video
- Public Safety



Additional Information:



LF
HF
VHF
UHF
SHF

Cellular: LTE Downlink

Technical Overview



- Modulation: OFDM
- Source: Data
- Channel Bandwidth: 1-20 MHz
- Channel Occupancy: Steady State

Example Application


- Mobile Networks
- Public Safety
- Mobile Internet

Common Frequency Range

- 590 MHz – 610 MHz
- 715 MHz – 765 MHz
- 1930 MHz – 2000 MHz
- 2110 MHz - 2180 MHz
- 2345 MHz – 2360 MHz
- LTE Frequency Bands



Additional Information:



LF
HF
VHF
UHF
SHF

Cellular: LTE Uplink

Technical Overview



- Modulation: OFDM
- Source: Data
- Channel Bandwidth: 1-20 MHz
- Channel Occupancy: TDMA

Example Application


- Mobile Networks
- Public Safety
- Mobile Internet

Common Frequency Range

- LTE Frequency Bands



Additional Information:



LF
HF
VHF
UHF
SHF

Cellular: UMTS Downlink

Technical Overview



- Modulation: CDMA
- Source: Data
- Channel Bandwidth: 3.84 MHz
- Channel Occupancy: Steady State

Example Application


- Cellular Networks
- Public Safety
- Portable Internet

Common Frequency Range

- 590 MHz – 610 MHz
- 715 MHz – 765 MHz
- 1930 MHz – 2000 MHz
- 2110 MHz - 2180 MHz
- 2345 MHz – 2360 MHz
- UMTS Frequency Bands



Additional Information:



LF
HF
VHF
UHF
SHF

Cellular: UMTS Uplink

Technical Overview



- Modulation: CDMA
- Source: Data
- Channel Bandwidth: 3.84 MHz
- Channel Occupancy: Steady State

Example Application


- Cellular Networks
- Public Safety
- Portable Internet

Common Frequency Range

- UMTS Frequency Bands



Additional Information:



LF
HF
VHF
UHF
SHF

Cellular: GSM

Technical Overview



- Modulation: Gaussian Minimal Shift Keying
- Source: Data
- Channel Bandwidth: 200 kHz
- Channel Occupancy: Time Division Duplex

Example Application


- Cellular Networks
- Public Safety
- Portable Internet

Common Frequency Range

- 824 MHz – 849 MHz
- 869 MHz – 894 MHz
- 1850 MHz – 1910 MHz
- 1930 MHz – 2000 MHz



Additional Information:



- LF
- HF
- VHF
- UHF
- SHF

Aeronautical: VHF Omni-Directional Radio Range (VOR)

Technical Overview



- Modulation: FSK
- Source: Data
- Channel Bandwidth: < 25 kHz
- Channel Occupancy: PTT

Example Application


- Cellular Networks
- Public Safety
- Portable Internet

Common Frequency Range

- 138 MHz – 174 MHz
- 410 MHz – 512 MHz
- 806 MHz – 902 MHz
- 928 MHz – 975 MHz



Additional Information:



LF
HF
VHF
UHF
SHF

Aeronautical: Airport Tower Communications

Technical Overview



- Modulation: AM
- Source: Voice
- Channel Bandwidth: < 25 kHz
- Channel Occupancy: PTT

Example Application


- Aircraft Communications

Common Frequency Range

- 108 MHz – 138 MHz



Additional Information:



LF
HF
VHF
UHF
SHF

Aeronautical: Automated Terminal Information System

Technical Overview



- Modulation: AM
- Source: Voice
- Channel Bandwidth: < 50 kHz
- Channel Occupancy: Continuous

Example Application



- Automated Airport Information Broadcast

Common Frequency Range

- 108 – 138 MHz



Additional Information:



RADAR

Technical Overview



- Modulation: None
- Source: CW
- Channel Bandwidth: < 50 MHz
- Channel Occupancy: Pulse

Example Application



- Weather
- Air Traffic Control

Common Frequency Range

- 5.6 GHz – 6 GHz
- 9 GHz – 10 GHz



Additional Information:



Resources

[USA \(FCC\) License Search](#)

[UK \(Of-com\) License Search](#)

[Signal Wiki](#)

[Canada \(IC-Spectrum\) License Search](#)

[Germany License Information](#)

[Antenna Theory](#)

[NTIA Frequency Allocation Chart](#)

[Radio Electronics](#)

Contact Tektronix:

ASEAN / Australia (65) 6356 3900
Austria* 00800 2255 4835
Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777
Belgium* 00800 2255 4835
Brazil +55 (11) 3759 7627
Canada 1 (800) 833-9200
Central East Europe and the Baltics +41 52 675 3777
Central Europe & Greece +41 52 675 3777
Denmark +45 80 88 1401
Finland +41 52 675 3777
France* 00800 2255 4835
Germany* 00800 2255 4835
Hong Kong 400-820-5835
Ireland* 00800 2255 4835
India +91-80-30792600
Italy* 00800 2255 4835
Japan 0120-441-046
Luxembourg +41 52 675 3777
Macau 400-820-5835
Mongolia 400-820-5835
Mexico, Central/South America & Caribbean 52 (55) 56 04 50 90
Middle East, Asia and North Africa +41 52 675 3777
The Netherlands* 00800 2255 4835
Norway 800 16098
People's Republic of China 400-820-5835
Poland +41 52 675 3777
Portugal 80 08 12370
Puerto Rico 1 (800) 833-9200
Republic of Korea +822-6917-5000
Russia +7 495 664 75 64
Singapore +65 6356-3900
South Africa +27 11 206 8360
Spain* 00800 2255 4835
Sweden* 00800 2255 4835
Switzerland* 00800 2255 4835
Taiwan 886-2-2656-6688
United Kingdom* 00800 2255 4835
USA 1 (800) 833-9200

* If the European phone number above is not accessible,
please call +41 52 675 3777

Contact List Updated June 2013

For Further Information

Tektronix maintains a comprehensive, constantly expanding collection of application notes, technical briefs and other resources to help engineers working on the cutting edge of technology. Please visit www.tektronix.com

Copyright © 2014, Tektronix. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks or registered trademarks of their respective companies.

11/14 EA/WWW

37W-30932-0

